WeatherMaker®

FURNACE CRITICAL PARTS



MINNESOTA AIR

952.918.8000

www.mnair.com

MINNESOTA AIR

MUCH MORE THAN AN HVAC DISTRIBUTOR™

Minnesota Air is a family-owned business dedicated exclusively to serving the HVAC industry. Our roots trace back to the early 1950s, when our first-generation owners founded one of the largest independent plumbing wholesalers in the United States. Minnesota Air was established in 1981 as a wholly owned subsidiary of that organization and, in 1999, became an independent corporation focused solely on HVAC.

Today, under third-generation family ownership, Minnesota Air is proud to be Minnesota's longest-tenured full-service HVAC distributorship. While our leadership continues to evolve, our commitment remains the same: delivering leading-edge equipment, parts, and supplies to heating, ventilation, air conditioning, and refrigeration contractors across Minnesota, Eastern North Dakota, and Western Wisconsin.

Through long-standing partnerships with our customers and manufacturers, we've built a reputation for excellence and assembled a team of experienced industry professionals. Our employees' deep knowledge and hands-on expertise - combined with thousands of hours of ongoing training provided both internally and to our partners - set Minnesota Air apart in the marketplace.

Additional Resources:

- Stocked Inventory
- Custom Freight
- Technical Support
- Training
- Marketing/Lead Generation Programs

We look forward to working alongside you, providing the tools, resources, and support needed to help you remain productive, profitable, and competitive in an ever-changing HVAC industry.

952.918.8000

www.mnair.com

MINNESOTA AIR

WeatherMaker®

WeatherMaker Furnaces & Parts



PG80SA

Product Details	
EFFICIENCY RATING	UP TO 80% AFUE
OPERATION	TWO-STAGE OPERATION
BLOWER MOTOR	FIXED SPEED BLOWER MOTOR FOR EVEN LEVELS OF TEMPERATURE CONTROL AND COMFORT
WARRANTY	10-YEAR PARTS LIMITED WARRANTY UPON TIMELY REGISTRATION*
HEAT EXCHANGER WARRANTY	20-YEAR HEAT EXCHANGER LIMITED WARRANTY*
HEATING CAPACITY	45,000-155,000 BUTh



PG80VTL

Product Details	
EFFICIENCY RATING	UP TO 80% AFUE
OPERATION	TWO-STAGE OPERATION
BLOWER MOTOR	VARIABLE-SPEED, CONSTANT TORQUE (VCT) ECM BLOWER MOTOR
WARRANTY	10-YEAR PARTS LIMITED WARRANTY UPON TIMELY REGISTRATION*
HEAT EXCHANGER WARRANTY	20-YEAR HEAT EXCHANGER LIMITED WARRANTY*
HEATING CAPACITY	45,000-135,000 BUTh

MINNESOTA AIR

WeatherMaker®

PG8MAA CRITICAL PARTS

PG8MAA036110AGJA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
336897-701	HARNESS ASSY
HR54ZA006	DOOR SWITCH
HB41TQ113	BLOWER MTR.
P291-1004	CAPACITOR
LA22ZA121	BLOWER WHEEL
EF32CW210	GAS VALVE
HH18HA507	LIMIT SWITCH
HH18HA495	TEMP SWITCH
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
326628-763	IND. MOTOR KIT
HC21ZE127	IND. MTR. ONLY
HK06WC100	PRESSURE SWITCH
326627-753	INDUCER HOUSING
(5) 326600-751	HEAT EX KIT.
326624-753	CELL PANEL KIT

PG8MAA048070AGJA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
336897-701	HARNESS ASSY
HR54ZA006	DOOR SWITCH
HB43TR113	BLOWER MTR.
P291-1504	CAPACITOR
LA22LA019	BLOWER WHEEL
EF32CW210	GAS VALVE
HH18HA508	LIMIT SWITCH
HH18HA495	TEMP SWITCH
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
326628-761	IND. MOTOR KIT
HC21ZE125	IND. MTR. ONLY
HK063WC100	PRESSURE SWITCH
326627-759	INDUCER HOUSING
(3) 326600-751	HEAT EX KIT.
326704-753	CELL PANEL KIT

PG8MAA042090AGJA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
336897-701	HARNESS ASSY
HR54ZA006	DOOR SWITCH
HB41TQ113	BLOWER MTR.
P291-1004	CAPACITOR
LA22ZA121	BLOWER WHEEL
EF32CW210	GAS VALVE
HH18HA502	LIMIT SWITCH
HH18HA495	TEMP SWITCH
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
326628-762	IND. MOTOR KIT
HC21ZE126	IND. MTR. ONLY
HK06WC100	PRESSURE SWITCH
326627-752	INDUCER HOUSING
(4) 326600-751	HEAT EX KIT.
326624-751	CELL PANEL KIT

PG8MAA024045AGJA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
326897-701	HARNESS ASSY
HR54ZA006	DOOR SWITCH
HC37TQ113	BLOWER MTR.
P291-1004	CAPACITOR
LA22RA101	BLOWER WHEEL
EF32CW210	GAS VALVE
HH18HA504	LIMIT SWITCH
HH18HA495	TEMP SWITCH
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
326628-760	IND. MOTOR KIT
HC21ZE124	IND. MTR. ONLY
HK06WC100	PRESSURE SWITCH
326627-751	INDUCER HOUSING
(2) 326600-751	HEAT EX KIT.
326704-751	CELL PANEL KIT

PG8MAA024070AGJA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
326897-701	HARNESS ASSY
HR54ZA006	DOOR SWITCH
HC37TQ113	BLOWER MTR.
P291-0754	CAPACITOR
LA22RA101	BLOWER WHEEL
EF32CW210	GAS VALVE
HH18HA502	LIMIT SWITCH
HH18HA495	TEMP SWITCH
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
326628-761	IND. MOTOR KIT
HC21ZE125	IND. MTR. ONLY
HK06WC100	PRESSURE SWITCH
326627-757	INDUCER HOUSING
(3) 326600-751	HEAT EX KIT.
326704-752	CELL PANEL KIT

PG8MAA036070AGJA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
336897-701	HARNESS ASSY
HR54ZA006	DOOR SWITCH
HB41TQ113	BLOWER MTR.
P291-0754	CAPACITOR
LA22RA101	BLOWER WHEEL
EF32CW210	GAS VALVE
HH18HA499	LIMIT SWITCH
HH18HA495	TEMP SWITCH
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
326628-761	IND. MOTOR KIT
HC21ZE125	IND. MTR. ONLY
HK06WC100	PRESSURE SWITCH
326628-758	INDUCER HOUSING
(3) 326600-751	HEAT EX KIT.
326704-752	CELL PANEL KIT

MINNESOTA AIR

WeatherMaker®

PG80MSA CRITICAL PARTS

PG80MSAA36045ABA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22RA101	WHEEL, BLOWER
HD42MQ120	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-701	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-760	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (2)	HEAT EXCHANGER KIT
HH18HA509	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA36070ABA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22RA101	WHEEL, BLOWER
HD42MQ120	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-702	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-760	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (3)	HEAT EXCHANGER KIT
HH18HA517	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA36070BBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA121	WHEEL, BLOWER
HD42MQ120	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-702	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-760	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (3)	HEAT EXCHANGER KIT
HH18HA497	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA42090BBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA121	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-703	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-762	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (4)	HEAT EXCHANGER KIT
HH18HA508	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA48090CBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA123	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-703	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-762	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (4)	HEAT EXCHANGER KIT
HH18HA508	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA60110CBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA120	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-704	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-763	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (5)	HEAT EXCHANGER KIT
HH18HA515	SWITCH, LIMIT
HH18HA586	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

MINNESOTA AIR

WeatherMaker®

PG80MSA CRITICAL PARTS

PG80MSAA60110DBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA120	WHEEL, BLOWER
HD46MQ152	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-704	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-764	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (5)	HEAT EXCHANGER KIT
HH18HA151	SWITCH, LIMIT
HH18HA507	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA60135DBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA120	WHEEL, BLOWER
HD46MQ152	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-705	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-763	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (6)	HEAT EXCHANGER KIT
HH18HA517	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80MSAA60155DBA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
LA22ZA120	WHEEL, BLOWER
HD46MQ152	MOTOR, BLOWER
EF32CW210	VALVE, GAS
326643-706	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-764	INDUCER MOTOR KIT, ALTERNATE
HH18HA493	SWITCH, TEMP
326600-751 (7)	HEAT EXCHANGER KIT
HH18HA508	SWITCH, LIMIT
HK06MC100	PRESSURE SWITCH

PG80VTLB CRITICAL PARTS

PG80VTLB36045AAA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
339965-701	HARNESS ASSEMBLY, MAIN
LA22RA101	WHEEL, BLOWER
HD44MM131	MOTOR, BLOWER
EF33CW180	VALVE, GAS
326643-701	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-760	INDUCER MOTOR KIT, PRIMARY
HH18HA493	SWITCH, TEMP
326600-751 (2)	HEAT EXCHANGER KIT
HH18HA509	SWITCH, LIMIT
HK06MC092	PRESSURE SWITCH (LOW)
HK06MC091	PRESSURE SWITCH (HIGH)

PG80VTLB36070AAA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
339965-701	HARNESS ASSEMBLY, MAIN
LA22RA101	WHEEL, BLOWER
HD44MM131	MOTOR, BLOWER
EF33CW180	VALVE, GAS
326643-702	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-761	INDUCER MOTOR KIT, PRIMARY
HH18HA493	SWITCH, TEMP
326600-751 (3)	HEAT EXCHANGER KIT
HH18HA499	SWITCH, LIMIT
HK06MC092	PRESSURE SWITCH (LOW)
HK06MC091	PRESSURE SWITCH (HIGH)

PG80VTLB48070BAA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
339965-701	HARNESS ASSEMBLY, MAIN
LA22LA019	WHEEL, BLOWER
HD46MM131	MOTOR, BLOWER
EF33CW180	VALVE, GAS
326643-702	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-761	INDUCER MOTOR KIT, PRIMARY
HH18HA493	SWITCH, TEMP
326600-751 (3)	HEAT EXCHANGER KIT
HH18HA508	SWITCH, LIMIT
HK06MC092	PRESSURE SWITCH (LOW)
HK06MC091	PRESSURE SWITCH (HIGH)

PG80VTLB48090BAA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
339965-701	HARNESS ASSEMBLY, MAIN
LA22ZA121	WHEEL, BLOWER
HD44MM131	MOTOR, BLOWER
EF33CW180	VALVE, GAS
326643-703	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-762	INDUCER MOTOR KIT, PRIMARY
HH18HA493	SWITCH, TEMP
326600-751 (5)	HEAT EXCHANGER KIT
HH18HA502	SWITCH, LIMIT
HK06MC092	PRESSURE SWITCH (LOW)
HK06MC091	PRESSURE SWITCH (HIGH)

PG80VTLB60090CAA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
339965-701	HARNESS ASSEMBLY, MAIN
LA22ZA120	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF33CW180	VALVE, GAS
326643-703	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-762	INDUCER MOTOR KIT, PRIMARY
HH18HA493	SWITCH, TEMP
326600-751 (4)	HEAT EXCHANGER KIT
HH18HA515	SWITCH, LIMIT
HK06MC092	PRESSURE SWITCH (LOW)
HK06MC091	PRESSURE SWITCH (HIGH)

PG80VTLB66110CAA

Part #	Description
HR54ZA006	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
339965-701	HARNESS ASSEMBLY, MAIN
LA680614	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF33CW180	VALVE, GAS
326643-704	BURNER ASSEMBLY
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLLOUT
349336-763	INDUCER MOTOR KIT, PRIMARY
HH18HA493	SWITCH, TEMP
326600-751 (5)	HEAT EXCHANGER KIT
HH18HA515	SWITCH, LIMIT
HH18HA586	SWITCH, LIMIT
HK06MC092	PRESSURE SWITCH (LOW)
HK06MC091	PRESSURE SWITCH (HIGH)

PG80VTLB48090BAA

Part #	Description	Part #	Description	Part #	Description
HR54ZA006	SWITCH, DOOR	HD52MM131	MOTOR, BLOWER	349336-764	INDUCER MOTOR KIT, PRIMARY
HK42FZ117	BOARD, CONTROL	EF33CW180	VALVE, GAS	HH18HA493	SWITCH, TEMP
HK70EA005	PLUG, MODEL	326643-705	BURNER ASSEMBLY	326600-751 (6)	HEAT EXCHANGER KIT
HT680054	TRANSFORMER	LH33ZG001	IGNITOR	HH18HA517	SWITCH, LIMIT
339965-701	HARNESS ASSEMBLY, MAIN	LH680534	SENSOR, FLAME	HK06MC092	PRESSURE SWITCH (LOW)
LA22ZA120	WHEEL, BLOWER	HH18HA495	SWITCH, FLAME ROLLOUT	HK06MC091	PRESSURE SWITCH (HIGH)

MINNESOTA AIR

WeatherMaker®



PG92S

Product Details	
EFFICIENCY RATING	UP TO 92.1% AFUE
OPERATION	SINGLE-STAG
BLOWER MOTOR	FIXED BLOWER MOTOR FOR EVEN LEVELS OF TEMPERATURE CONTROL AND COMFORT
ENERGY STAR QUALIFIED	SELECT SIZES
WARRANTY	10-YEAR PARTS LIMITED WARRANTY UPON TIMELY REGISTRATION*
HEAT EXCHANGER WARRANTY	20-YEAR HEAT EXCHANGER LIMITED WARRANTY*
HEATING CAPACITY	40,000-120,000 BUTh

PG92S CRITICAL PARTS

PG8MAA036110AGJA

Part #	Description
HK42FZ036	CONTROL BOARD
HT680054	TRANSFORMER
338485-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HC43TQ115	BLOWER MTR.
P291-1503	CAPACITOR
LA22LA019	BLOWER WHEEL
EF32CW151	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB020	PRESSURE SWITCH
336771-763	HEAT EX KIT. PRIMARY
336774-764-CBP	CONDENSING HT EX.
336772-753-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
336850-752-CBP	COLLECTOR BOX
338096-706	LIMIT SWITCH

PG92SCS30040AAAA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
339855-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HB41TR104	BLOWER MTR.
P291-0754	CAPACITOR
LA22LA029	BLOWER WHEEL
EF32CW151	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-776-CBP	IND. MOTOR KIT
HK06NB020	PRESSURE SWITCH
336771-758	HEAT EX KIT. PRIMARY
336774-772-CBP	CONDENSING HT EX.
336772-751-CBP	CELL PANEL KIT
337533-751-CBP	COUPLING BOX
339707-751-CBP	COLLECTOR BOX
338096-711	LIMIT SWITCH

PG92SCS48060BAAA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
338955-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HC43TE114	BLOWER MTR.
P291-1004	CAPACITOR
LA22LA019	BLOWER WHEEL
EF32CW151	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB020	PRESSURE SWITCH
336771-763	HEAT EX KIT. PRIMARY
336774-774-CBP	CONDENSING HT EX.
336772-763-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
339707-752-CBP	COLLECTOR BOX
HH12ZZ190	LIMIT SWITCH

PG92SCS60080CAAA

Part #	Description	Part #	Description	Part #	Description
HK42FZ061	CONTROL BOARD	LA680593	BLOWER WHEEL	336774-776-CBP	CONDENSING HT EX.
HT680054	TRANSFORMER	EF32CW151	GAS VALVE	336772-768-CBP	CELL PANEL KIT
339855-701	HARNESS ASSY	LH680534	FLAME SENSOR	337533-752-CBP	COUPLING BOX
HH18HA495	ROLL OUT # 1	LH33ZG001	IGNITOR	339707-753-CBP	COLLECTOR BOX
HH18HA495	ROLL OUT # 2	337938-785-CBP	IND. MOTOR KIT	338096-711	LIMIT SWITCH
HC45TQ125	BLOWER MTR.	HK06NB020	PRESSURE SWITCH	336774-754-CBP	Sec. Heat Ex.
P291-2504	CAPACITOR	336771-764	HEAT EX KIT. PRIMARY		

MINNESOTA AIR

WeatherMaker®

PG92MSAA CRITICAL PARTS

PG92MSAA36040AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA023	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-772-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH18HA123	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG92MSAA36040BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-773-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH18HA123	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG92MSAA36060AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA023	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-752-CBP	PRIMARY HEAT EXCHANGER KIT
347328-772-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
348224-716	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG92MSAA42060BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-763	PRIMARY HEAT EXCHANGER KIT
347328-774-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH12ZZ230	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG92MSAA48080BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MQ151	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-754	PRIMARY HEAT EXCHANGER KIT
347328-775-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH12ZZ205	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG92MSAA60080CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD46MQ151	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-754	PRIMARY HEAT EXCHANGER KIT
347328-776-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH12ZZ185	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

WeatherMaker®

PG92MSAA CRITICAL PARTS

PG92MSAA60100CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD46MQ151	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-754-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-756	PRIMARY HEAT EXCHANGER KIT
347328-777-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-710	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG92MSAA60120DAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA120	WHEEL, BLOWER
HD46MQ151	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-755-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-757	PRIMARY HEAT EXCHANGER KIT
347328-778-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH12ZZ150	LIMIT SWITCH ASSEMBLY
HK06MB028	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

WeatherMaker®

PG95ESAA CRITICAL PARTS

PG95ESAA30040AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
344269-401	WHEEL, BLOWER
HD44NQ301	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-752-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-706	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA36040BBA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
RC6600126	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-753-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA36060AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
344269-401	WHEEL, BLOWER
HD44NQ302	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-752-CBP	PRIMARY HEAT EXCHANGER KIT
347328-752-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-713	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA42060BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MQ144	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-763	PRIMARY HEAT EXCHANGER KIT
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA48080BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MM120	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-764	PRIMARY HEAT EXCHANGER KIT
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-702	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA60080CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD52MQ136	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-753-CBP	COLLECTOR BOX KIT
347329-764	PRIMARY HEAT EXCHANGER KIT
347328-755-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-707	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

WeatherMaker®

PG95ESAA CRITICAL PARTS

PG95ESAA60100CAA	
Part #	**Description**
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD52MM120	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-754-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
347318-753-CBP	COLLECTOR BOX KIT
347329-756	PRIMARY HEAT EXCHANGER KIT
347328-756-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA66120DAA	
Part #	**Description**
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22ZA120	WHEEL, BLOWER
HD52MQ137	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-755-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-757	PRIMARY HEAT EXCHANGER KIT
347328-757-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH12ZZ150	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG95ESAA66140DAA	
Part #	**Description**
HR54ZA008	SWITCH, DOOR
HK42FZ086	BOARD, CONTROL
HT680054	TRANSFORMER
339855-701	MAIN HARNESS ASSEMBLY
LA22ZA120	WHEEL, BLOWER
HD52MM121	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-756-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-787-CBP	INDUCER MOTOR/HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-759-CBP	PRIMARY HEAT EXCHANGER KIT
347328-759-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
HH12ZZ190	LIMIT SWITCH ASSEMBLY
HK06MB028	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

WeatherMaker®



PG95S

Product Details	
EFFICIENCY RATING	UP TO 96.0% AFUE
OPERATION	SINGLE-STAGE
BLOWER MOTOR	FIXED SPEED BLOWER MOTOR FOR EVEN LEVELS OF TEMPERATURE CONTROL AND COMFORT
ENERGY STAR QUALIFIED	SELECT SIZES
WARRANTY	10-YEAR PARTS LIMITED WARRANTY UPON TIMELY REGISTRATION*
HEAT EXCHANGER WARRANTY	20-YEAR HEAT EXCHANGER LIMITED WARRANTY*
HEATING CAPACITY	26,000-140,000 BUTh

PG95S CRITICAL PARTS

PG95SAS30040AAAA

Part #	Description
HK42FZ036	CONTROL BOARD
HT680054	TRANSFORMER
338485-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HC43TQ114	BLOWER MTR.
P291-1504	CAPACITOR
LA22LA029	BLOWER WHEEL
EF32CW151	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-776-CBP	IND. MOTOR KIT
HK06NB012	PRESSURE SWITCH
336771-758	HEAT EX KIT. PRIMARY
336774-752-CBP	CONDENSING HT EX.
336772-751-CBP	CELL PANEL KIT
337533-751-CBP	COUPLING BOX
339707-751-CBP	COLLECTOR BOX
338096-703	LIMIT SWITCH

PG95SAS42060BBAA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
338485-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HC43TQ115	BLOWER MTR.
P291-1504	CAPACITOR
LA22LA019	BLOWER WHEEL
EF32CW151	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB012	PRESSURE SWITCH
336771-763	HEAT EX KIT. PRIMARY
336774-754-CBP	CONDENSING HT EX.
336772-753-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
339707-752-CBP	COLLECTOR BOX
338096-701	LIMIT SWITCH

PG95SAS48080BBAA

Part #	Description
HK42FZ061	CONTROL BOARD
HT680054	TRANSFORMER
338485-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA495	ROLL OUT # 2
HC45TQ125	BLOWER MTR.
P291-2504	CAPACITOR
LA22LA019	BLOWER WHEEL
EF32CW151	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB020	PRESSURE SWITCH
336771-764	HEAT EX KIT. PRIMARY
336774-754-CBP	CONDENSING HT EX.
336772-764-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
339707-752-CBP	COLLECTOR BOX
338096-702	LIMIT SWITCH

PG95SAS60100CAAA

Part #	Description	Part #	Description	Part #	Description
HK42FZ036	CONTROL BOARD	LA680593	BLOWER WHEEL	336774-756-CBP	CONDENSING HT EX.
HT680054	TRANSFORMER	EF32CW151	GAS VALVE	336772-756-CBP	CELL PANEL KIT
338485-701	HARNESS ASSY	LH680534	FLAME SENSOR	337533-753-CBP	COUPLING BOX
HH18HA495	ROLL OUT # 1	LH33ZG001	IGNITOR	339707-753-CBP	COLLECTOR BOX
HH18HA495	ROLL OUT # 2	337938-786-CBP	IND. MOTOR KIT	338096-701	LIMIT SWITCH
HC52TQ145	BLOWER MTR.	HK06NB021	PRESSURE SWITCH	336774-757-CBP	Sec. Heat Ex.
P291-3504	CAPACITOR	336771-756	HEAT EX KIT. PRIMARY		

MINNESOTA AIR

WeatherMaker®

PG96MSAA CRITICAL PARTS

PG96MSAA30040AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
344269-401	WHEEL, BLOWER
HD44NQ304	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-752-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-706	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA36040BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD44MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-753-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA36060AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
344269-401	WHEEL, BLOWER
HD44NQ304	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-752-CBP	PRIMARY HEAT EXCHANGER KIT
347328-752-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-713	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA48060BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MQ151	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-763	PRIMARY HEAT EXCHANGER KIT
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA48080BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-754	PRIMARY HEAT EXCHANGER KIT
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-702	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA60080CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-754	PRIMARY HEAT EXCHANGER KIT
347328-755-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-707	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

WeatherMaker®

PG96MSAA CRITICAL PARTS

PG96MSAA60100CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD52MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-754-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-756	PRIMARY HEAT EXCHANGER KIT
347328-756-CBP	SECONDARY (CONDENSING) HEAT EXHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA66120DAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA120	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-755-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-757	PRIMARY HEAT EXCHANGER KIT
347328-757-CBP	SECONDARY (CONDENSING) HEAT EXHANGER KIT
HH12ZZ150	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96MSAA66140DAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ112	BOARD, CONTROL
HK70EA005	PLUG, SUPER
HT680054	TRANSFORMER
346306-701	MAIN HARNESS ASSEMBLY
LA22ZA120	WHEEL, BLOWER
HD52MM130	MOTOR, BLOWER
EF32CW151	VALVE, GAS
336842-756-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-787-CBP	INDUCER MOTOR/HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-759-CBP	PRIMARY HEAT EXCHANGER KIT
347328-759-CBP	SECONDARY (CONDENSING) HEAT EXHANGER KIT
HH12ZZ190	LIMIT SWITCH ASSEMBLY
HK06MB028	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

WeatherMaker®



PG96V

Product Details	
EFFICIENCY RATING	UP TO 96.0% AFUE
OPERATION	TWO-STAGE
BLOWER MOTOR	VARIABLE-SPEED, CONSTANT AIRFLOW (VCA) ECM BLOWER MOTOR
ENERGY STAR QUALIFIED	U.S. ENVIRONMENTAL PROTECTION AGENCY VOLUNTARY PROGRAM THAT HELPS PROTECT CLIMATE THROUGH ENERGY EFFICIENCY
WARRANTY	10-YEAR PARTS LIMITED WARRANTY UPON TIMELY REGISTRATION*
HEAT EXCHANGER WARRANTY	20-YEAR HEAT EXCHANGER LIMITED WARRANTY*

95X-96V CRITICAL PARTS

PG95XAT42060BBAA

Part #	Description
HK42FZ040	CONTROL BOARD
HT680054	TRANSFORMER
337551-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HD46MQ133	BLOWER MTR.
LA22LA019	BLOWER WHEEL
EF33CW152	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB012	PRESSURE SWITCH
336771-763	HEAT EX KIT. PRIMARY
336774-754-CBP	CONDENSING HT EX.
336772-753-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
339707-752-CBP	COLLECTOR BOX
336836-751	CONDENSATE TRAP
338096-701	LIMIT SWITCH

PG95XAT48080BBAA

Part #	Description
HK42FZ040	CONTROL BOARD
HT680054	TRANSFORMER
337551-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HD43MQ134	BLOWER MTR.
LA22LA019	BLOWER WHEEL
EF33CW152	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB020	PRESSURE SWITCH
336771-764	HEAT EX KIT. PRIMARY
336774-754-CBP	CONDENSING HT EX.
336772-764-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
339707-752-CBP	COLLECTOR BOX
336836-751	CONDENSATE TRAP
338096-702	LIMIT SWITCH

PG96VAT42060BCAA

Part #	Description
HK42FZ066	CONTROL BOARD
HT600054	TRANSFORMER
337675-701	HARNESS ASSY
HH18HA495	ROLL OUT # 1
HH18HA587	ROLL OUT # 2
HD46MR125	BLOWER MTR.
LA22LA019	BLOWER WHEEL
EF33CW152	GAS VALVE
LH680534	FLAME SENSOR
LH33ZG001	IGNITOR
337938-785-CBP	IND. MOTOR KIT
HK06NB012	PRESSURE SWITCH
336771-763	HEAT EX KIT. PRIMARY
336774-754-CBP	CONDENSING HT EX.
336772-753-CBP	CELL PANEL KIT
337533-752-CBP	COUPLING BOX
339707-752-CBP	COLLECTOR BOX
33096-701	LIMIT SWITCH
338096-701	LIMIT SWITCH

PG96VAT48080BCAA

Part #	Description	Part #	Description	Part #	Description
HK42FZ066	CONTROL BOARD	EF33CW152	GAS VALVE	336772-764-CBP	CELL PANEL KIT
HT600054	TRANSFORMER	LH680534	FLAME SENSOR	337533-752-CBP	COUPLING BOX
337675-701	HARNESS ASSY	LH33ZG001	IGNITOR	339707-752-CBP	COLLECTOR BOX
HH18HA495	ROLL OUT # 1	337938-774-CBP	IND. MOTOR KIT	338096-702	LIMIT SWITCH
HH18HA495	ROLL OUT # 2	HK06NB020	PRESSURE SWITCH	336771-763	Prim. Heat Ex.
HD46MR125	BLOWER MTR.	336771-764	HEAT EX KIT. PRIMARY	336774-774-CBP	Sec. Heat Ex.
LA22LA019	BLOWER WHEEL	336774-754-CBP	CONDENSING HT EX.		

PG96VTAB CRITICAL PARTS

PG96VTAB30040AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
344269-401	WHEEL, BLOWER
HD44NQ304	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
348558-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-752-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-706	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB36040BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD44MM131	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-751-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
348558-784-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-758	PRIMARY HEAT EXCHANGER KIT
347328-753-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB36060AAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
344269-401	WHEEL, BLOWER
HD44NQ304	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-751-CBP	COLLECTOR BOX KIT
347329-752-CBP	PRIMARY HEAT EXCHANGER KIT
347328-752-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-713	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB48060BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MQ151	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-763	PRIMARY HEAT EXCHANGER KIT
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB CRITICAL PARTS

PG96VTAB48080BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
LA22LA019	WHEEL, BLOWER
HD46MM131	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-754	PRIMARY HEAT EXCHANGER KIT
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-702	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB60080CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR/HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-754	PRIMARY HEAT EXCHANGER KIT
347328-755-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-707	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB60100CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
LA22ZA127	WHEEL, BLOWER
HD52MQ143	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-754-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-756	PRIMARY HEAT EXCHANGER KIT
347328-756-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG96VTAB66120DAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	MAIN HARNESS ASSEMBLY
LA22ZA120	WHEEL, BLOWER
HD52MM131	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-755-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR/HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-757	PRIMARY HEAT EXCHANGER KIT
347328-757-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-715	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
336836-751	CONDENSATE TRAP KIT

PG97VTAA CRITICAL PARTS

PG97VTAA48060BAA

Part #	Description
HR54ZAC	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	HARNESS ASSEMBLY MAIN
LA22LA019	FAN, BLOWER WHEEL
HD46MQ151	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-752-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA587	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR HOUSING KIT
339707-752-CBP	COLLECTOR BOX KIT
347329-763	HEAT EXCHANGER KIT, PRIMARY
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB012	SWITCH, PRESSURE
337533-752-CBP	COUPLING BOX KIT
336836-751	CONDENSATE TRAP KIT

PG97VTAA48080BAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	HARNESS ASSEMBLY MAIN
LA22LA019	FAN, BLOWER WHEEL
HD46MM131	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR HOUSING KIT
347318-752-CBP	COLLECTOR BOX KIT
347329-754	HEAT EXCHANGER KIT, PRIMARY
347328-754-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-702	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
337533-752-CBP	COUPLING BOX KIT
336836-751	CONDENSATE TRAP KIT

PG97VTAA60080CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	HARNESS ASSEMBLY MAIN
LA22ZA127	FAN, BLOWER WHEEL
HD52MQ143	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-753-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-785-CBP	INDUCER MOTOR HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-754	HEAT EXCHANGER KIT, PRIMARY
347328-755-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-707	LIMIT SWITCH ASSEMBLY
HK06MB020	SWITCH, PRESSURE
337533-752-CBP	COUPLING BOX KIT
336836-751	CONDENSATE TRAP KIT

PG97VTAA60100CAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	HARNESS ASSEMBLY MAIN
LA22ZA127	FAN, BLOWER WHEEL
HD52MQ143	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-754-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR HOUSING KIT
339707-753-CBP	COLLECTOR BOX KIT
347329-756	HEAT EXCHANGER KIT, PRIMARY
347328-756-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-701	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
337533-753-CBP	COUPLING BOX KIT
336836-751	CONDENSATE TRAP KIT

PG97VTAA66120DAA

Part #	Description
HR54ZA008	SWITCH, DOOR
HK42FZ117	BOARD, CONTROL
HK70EA005	PLUG, MODEL
HT680054	TRANSFORMER
337675-701	HARNESS ASSEMBLY MAIN
LA22ZA120	FAN, BLOWER WHEEL
HD52MM131	MOTOR, BLOWER
EF33CW152	VALVE, GAS
336842-755-CBP	BURNER KIT
LH33ZG001	IGNITOR
LH680534	SENSOR, FLAME
HH18HA495	SWITCH, FLAME ROLL-OUT (RS1)
HH18HA495	SWITCH, FLAME ROLL-OUT (RS2)
337938-786-CBP	INDUCER MOTOR HOUSING KIT
347318-754-CBP	COLLECTOR BOX KIT
347329-757	HEAT EXCHANGER KIT, PRIMARY
347328-757-CBP	SECONDARY (CONDENSING) HEAT EXCHANGER KIT
338096-715	LIMIT SWITCH ASSEMBLY
HK06MB021	SWITCH, PRESSURE
337533-754-CBP	COUPLING BOX KIT
336836-751	CONDENSATE TRAP KIT

MINNESOTA AIR

MUCH MORE THAN AN HVAC DISTRIBUTOR

952.918.8000 www.mnair.com

Bloomington - Distribution Center

6901 W Old Shakopee Rd, Bloomington, MN 55438

Open Monday - Friday: 7:00 AM - 5:00 PM

Open Saturday: 8:00 AM - 12:00 PM - OPT 6

Will Call is open until 10:00 PM, Monday - Friday.

If picking up after 5:00 PM, you MUST reference an order number.

Lake Elmo - Distribution Center:

11190 Hudson Blvd N Suite 100, Lake Elmo, MN 55042

Open Monday - Friday: 7:00 AM - 5:00 PM

Open Saturday: 8:00 AM - 12:00 PM - OPT 6

Will Call is open until 10:00 PM, Monday - Friday.

If picking up after 5:00 PM, you MUST reference an order number.

St. Cloud - Distribution Center

6704 8th Ave S Suite 100, St. Cloud, MN 56301

Open Monday - Friday: 7:00 AM - 5:00 PM

Crystal - City Desk

5524 Lakeland Ave N, Crystal, MN 55429

Open Monday - Friday: 7:00 AM - 5:00 PM

After Hours Emergency Service

612.790.3110

Additional Fees May Apply

****Note about calling for parts. All equipment orders need to be placed online and referenced after calling****

WeatherMaker®

Order Online

www.mnair.com

Online Training

www.mnairacademy.com